

Product information presented here reflects conditions at time of publication. Consult factory regarding discrepancies or inconsistencies.



**PUMP COMPANY**

Zoeller Family of Water Solutions™

**MAIL TO:** P.O. BOX 16347 • Louisville, KY 40256-0347  
**SHIP TO:** 3649 Cane Run Road • Louisville, KY 40211-1961  
 (502) 778-2731 • 1 (800) 928-PUMP • FAX (502) 774-3624

**visit our web site:**  
**www.zoeller.com**

## MODEL 10-2614 APAK® ALARM SYSTEMS WITH AUXILLIARY CONTACTS WIRING INSTRUCTIONS



**▲ WARNING** ELECTRICAL SHOCK HAZARD - Disconnect all power sources before servicing. Failure to do so could result in serious injury or death.

- 1) Remove the three screws from the back of the enclosure as shown in Fig. A.
- 2) Remove the back of the enclosure. Note the position of the power cord in the enclosure. The cord will need to be located in the same manner when the enclosure back is replaced.
- 3) Determine the location where the auxiliary contact wires will enter the housing. See Fig. B for recommended location. Before drilling the hole, loosen the circuit board mounting screw and remove the circuit board. See Fig. C.
- 4) At the selected location, drill a hole in the enclosure suitable for the strain relief that will be used (strain relief not included).
- 5) Install strain relief and reinstall the circuit board. Connect wires to the terminal block shown in Fig. C.
- 6) Markings on the circuit board show positions for Common (C), Normally Open (NO), and Normally Closed (NC).

- 7) Position the power cord into place as it was prior to removing the enclosure back as shown in Fig. C.

- 8) Reinstall the enclosure back and three screws.

**▲ CAUTION** Do not over torque screws. Screw bosses may become stripped.


- 9) Note that while testing the installed product, the auxiliary alarm wired to the auxiliary contacts should activate in an alarm condition. The auxiliary alarm should also remain in alarm condition when the silence button is pushed.

### Auxiliary Contacts Specifications


Voltage: 120 VAC  
 Current: 5 amps max. N/O  
 3 amps max. N/C

**NOTE:** This unit includes auxiliary contact option. Due to increased power consumption, if an alarm condition occurs while on battery backup power, this option will reduce the life of the battery.


**Figure A**



**Figure B**



**Figure C**



**▲ WARNING**

All electrical systems must be installed by a qualified licensed electrician according to the National Electrical Code and all other applicable codes.

SK2775

# BELL ALARM SYSTEMS

## TYPICAL INSTALLATION AND WIRING INSTRUCTIONS





All electrical systems must be installed by a qualified licensed electrician according to the National Electrical Code and all other applicable codes.

Model	Voltage	dB @ 10'	Bell	Transformer	Float
10-0015	115V	74	✓	✓	
10-0016	230V	74	✓	✓	
10-0028	115V	78	✓	✓	✓

NOTE: Utility box and cordage sold separately. Bell Alarms 10-0015 and 10-0016 are designed to be used with Alarm Pack 10-2614.

### TYPICAL SIMPLEX SYSTEMS WITH BELL ALARM SYSTEM




### WIRING DIAGRAM

(10-0015)  
(10-0016)  
(10-0028)

DISCONNECT NOT SHOWN

**NOTE: ALARM SYSTEM SHOULD BE ON A SEPARATE CIRCUIT FROM PUMPS.**



**PUMP COMPANY**

MAIL TO: P.O. BOX 16347 • Louisville, KY 40256-0347  
SHIP TO: 3649 Cane Run Road • Louisville, KY 40211-1961  
(502) 778-2731 • 1 (800) 928-PUMP • FAX (502) 774-3624

*Your Peace of Mind is Our Top Priority®*

visit our web site:  
[www.zoeller.com](http://www.zoeller.com)